



Finium guarantees the conformity of its products when they are installed according to the installation instructions and are maintained in an environment where ambient humidity ranges between 35% and 55%: before, during and after installation.

PRECAUTIONS

Always wear work gloves and safety glasses when installing the product.



INSTALLATION INSTRUCTIONS

Tools:


- 100% polyurethane construction glue (3 tubes per 100 ft² or 10 m²)
- Caulking gun
- Electric mitre saw
- Table saw
- Level
- Measuring tape
- Cutter
- Pneumatic finish hammer (#23 gauge finish nail)
- Stepladder

MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN PRIME CONDITION.

First, check the wall(s) is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.


STEP 1: If you are using moldings, leave space accordingly around the perimeter of your installation area.

STEP 2: Cut a minimum of 6" (15 cm) from the male side of your first panel, save the female cut section of the panel to start the wall.



STEP 3:

A: Apply a line of 100% polyurethane glue in the form of a rectangle (1/2" (1.3 cm) from edges) and an X inside the rectangle.




B: Apply glue at the edges of each piece.




LEAVE THE BOX IN THE ROOM IT IS TO BE INSTALLED FLAT ON THE FLOOR IN ITS ORIGINAL WRAPPING UNTIL INSTALLATION.

STEP 4: Position the first panel at the lower left section of the wall in the adjustment area if you are using moldings.



STEP 5: Nail the panel in place with #23 gauge finish nails on the contour lips and on the two bottom rows in angles between wood pieces. NEVER NAIL DIRECTLY ON THE FACE OF THE NARROW WOOD PIECES.



STEP 6: Installation of subsequent panels

- Repeat the gluing procedure
- Insert panel B into panel A
- Repeat the nailing procedure



STEP 7: End a row

Cut any excess of the wall panel to be flush with the edge of the wall.

STEP 8: Start a new row

Use the panel cut in Step 7 to begin the new row. Repeat Step 3, 4 and 5.

STEP 9: Last row

Cut the panels of the last row lengthwise to fit the given space. Allow enough space for the molding if necessary.

STEP 10: Insert the molding in the reserved space set at the beginning of the installation if needed.

NOTE: if wood pieces detaches from a wall panel, reposition using 100% polyurethane glue.

THE WALL PANEL NEEDS TO BE GLUED AND NAILED FOR A SUCCESSFUL INSTALL AND TO PREVENT FUTURE WARPING. FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS SHALL VOID THE APPLICATION OF THE WARRANTY.

Do not install over material other than drywall and plywood.

View our installation video before getting started: www.finium.ca



Finium guarantees the conformity of its products when they are installed according to the installation instructions and are maintained in an environment where ambient humidity ranges between 35% and 55%: before, during and after installation.

BRACE WALL PANEL

PRECAUTIONS

Always wear work gloves and safety glasses when installing the product.



LEAVE THE BOX IN THE ROOM IT IS TO BE INSTALLED FLAT ON THE FLOOR IN ITS ORIGINAL WRAPPING UNTIL INSTALLATION.

INSTALLATION INSTRUCTIONS


Tools :

- 100% polyurethane construction glue (3 tubes per 100 ft² or 10 m²)
- Caulking gun
- Electric mitre saw
- Table saw
- Level
- Mesuring tape
- Cutter
- Pneumatic finish hammer (#23 gauge finish nail)
- Stepladder


MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN PRIME CONDITION.

First, check the wall(s) is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.



STEP 1: Cut any excess tab of the wall panel.




STEP 2: A: Apply a line of 100% polyurethane glue in the form of a rectangle (1/2" (1,3 cm) from edges) and a X inside the rectangle.



B: Apply glue at the edge.



STEP 3: Position the first panel vertically at the bottom right. Make sure each panel and column are level.



STEP 4: Nail the panel in place with #23 gauge nails on the contour lips.

STEP 5: → Installation of subsequent panels

- Repeat the gluing procedure
- Align panel **B** against **A**
- Repeat the nailing procedure

STEP 6:


End a column

Cut any excess of the wall panel to be flush with the edge of the wall.

STEP 7:

Start a new column

Use the remaining piece from the previous column and cut to fit. Repeat step 2 and add glue on the vacant backing of the adjacent wall panel installed.



STEP 8:

Last column

Cut the panel on the left to fit.

NOTE: if wood pieces detaches from a wall panel, reposition using 100% polyurethane glue.

THE WALL PANEL NEEDS TO BE GLUED AND NAILED FOR A SUCCESSFUL INSTALL AND TO PREVENT FUTURE WARPING. FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS SHALL VOID THE APPLICATION OF THE WARRANTY.

Do not install over material other than drywall and plywood.




FINIUM®

BREEZEWAY WALL PANEL

PRECAUTIONS

Always wear work gloves and safety glasses when cutting the product. Read the installation instructions and warranty before getting started.



Finium guarantees the conformity of its products when they are installed according to the installation instructions and are maintained in an environment where ambient humidity ranges between 35% and 55%. Failure to comply with installation instructions shall void the application of the Warranty.

LEAVE THE BOX FLAT ON THE FLOOR IN ITS ORIGINAL WRAPPING UNTIL INSTALLATION.

INSTALLATION INSTRUCTIONS

Tools:


- 100% polyurethane construction glue (3 tubes per 100 ft² or 10 m²)
- Construction glue applicator
- Electric mitre saw
- Sawbench
- Level
- Measuring tape
- X-Acto type knife
- Pneumatic finish hammer (# 23 nails)
- Stepladder

MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN PRIME CONDITION.


First, check the wall(s) is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.

STEP 1:


A: Apply a line of 100% polyurethane glue in the form of a rectangle (1/2" (1.3 cm) from edges) and an X inside the rectangle.



STEP 2: Position the first panel at the lower left section of the wall. Plywood lip to be facing up and right. Make sure the wall panel and row are level.




STEP 3: Nail the panel in place with #23 nails on the contour lips and on the two bottom rows in angles between wood pieces. NEVER NAIL DIRECTLY ON THE FACE OF THE NARROW WOOD PIECES.



STEP 4: Installation of subsequent panels

- Repeat the gluing procedure
- Align panel B against A
- Repeat the nailing procedure



STEP 5: End a row

Before installing the last panel in a row, measure from the top row of the panel already installed where installation is to be completed. The remaining section of panel will serve as the first panel in the next row.

STEP 6: Start a new row

To start a new row, repeat step 1 by using the remaining piece from the first row. Repeat step 2 and 3.

STEP 7: Last row

Cut the panels of the last row lengthwise to fit the given space.

NOTE: if wood pieces detaches from a wall panel, reposition using 100% polyurethane glue.

FINIUM RECOMMENDS THAT YOU VIEW OUR INSTALLATION VIDEO BEFORE GETTING STARTED:
www.finium.ca

This is a glue AND nail installation.
Do not install over material other than gypse and plywood.



HAYLOFT WALL PANEL

PRECAUTIONS

Always wear work gloves and safety glasses when cutting the product.



INSTALLATION INSTRUCTIONS

- Each box contains 4 wall panels and 16 wood slats


Tools:

- 100% polyurethane construction glue (3 tubes per 100 ft² or 10 m²)
- Caulking gun
- Electric mitre saw
- Table saw
- Level
- Measuring tape
- Cutter
- Pneumatic finish hammer (#23 gauge finish nail)
- Stepladder


MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN PRIME CONDITION.

First, check the wall(s) is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.


STEP 1 : Cut the excess of the plywood on the left side.



STEP 2: Apply a line of 100% polyurethane glue in the form of a rectangle (1/2" (1.3 cm) from edges) and an X inside the rectangle.




STEP 3 : Starting from the bottom left, place the wall panel horizontally, the cut side to the left. Make sure each wall panel and row are level.



Finium guarantees the conformity of its products when they are installed according to the installation instructions and are maintained in an environment where ambient humidity ranges between 35% and 55%: before, during and after installation.

LEAVE THE BOX FLAT ON THE FLOOR IN ITS ORIGINAL WRAPPING AND IN THE ROOM IT IS TO BE INSTALLED UNTIL INSTALLATION.

STEP 4 : Nail the panel in place with #23 gauge finish nails on the contour lips and within the empty spaces. NEVER NAIL DIRECTLY ON THE FACE OF THE WALL PANEL.




STEP 5 : Installation of subsequent panels and wood slats

A Glue and nail in place a wood slat on the right hand side of the installed panel.

B Second panel to install ; repeat step 2 and slide under the wood slat against the first panel.

C Repeat step 4.



STEP 6 : End a row

- At the end of a row, glue the wood slats on the top of the panels where they are intended.
- For the bottom and each end, the wood slats must be cut and then glued in place.

STEP 7 : Start a new row

- To start a new row, repeat step 1 or use the remaining pieces, making sure to respect the pattern from the previous row.

STEP 8 : Last row

Cut the panels of the last row lengthwise to fit the given space.

NOTE : If wood pieces detaches from a wall panel, reposition using 100% polyurethane glue.

THE WALL PANEL NEEDS TO BE GLUED AND NAILED FOR A SUCCESSFUL INSTALL AND TO PREVENT FUTURE WARPING. FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS SHALL VOID THE APPLICATION OF THE WARRANTY.

Do not install over material other than drywall and plywood.



Finium guarantees the conformity of its products when they are installed according to the installation instructions and are maintained in an environment where ambient humidity ranges between 35% and 55%: before, during and after installation.

COUNTRYSIDE WOOD PLANKS

PRECAUTIONS

Always wear work gloves and safety glasses when installing the product.



INSTALLATION INSTRUCTIONS


Tools :

- 100% polyurethane construction glue (3 tubes per 100 ft² or 10 m²)
- Caulking gun
- Electric mitre saw
- Table saw
- Level
- Mesuring tape
- Cutter
- Pneumatic finish hammer (#23 gauge finish nail)
- Stepladder


MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN PRIME CONDITION.

First, check the wall(s) is level from floor to ceiling and edge-to-edge. If not, adjust accordingly.


STEP 1: Start with the the flat (A) piece first and cut to desired length.



STEP 2: Apply adhesive on the back of the wood plank.



STEP 3: Position the wood plank at the bottom right or left. Make sure each piece is level.




STEP 4: Nail the wood plank in place with #23 gauge nails on the side where the T-plank (B) is to be installed.

STEP 5: End a column


Cut any excess of the wood plank to be flush with the edge of the wall. Repeat step 2 and 4.

STEP 6: Start a new column

Use the T-plank (B) and cut to desired length. Repeat step 2 and slide the wood plank against the plank installed. Leave a small gap for expansion.



STEP 7: Nail the wood plank in angles using #23 gauge nails, on the side that overlaps the plank already installed.



STEP 8: Third column and so forth

Alternate pieces (A - B) and repeat the gluing and nailing process.

STEP 9: Last column

Cut the wood plank to fit.

THE WOOD PLANK NEEDS TO BE GLUED AND NAILED FOR A SUCCESSFUL INSTALL AND TO PREVENT FUTURE WARPING. FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS SHALL VOID THE APPLICATION OF THE WARRANTY.

Do not install over material other than drywall and plywood.